

# Краткое приложение IRC 145 F (версия 21.07.02 03:03)

Модели оригинальных пультов и соответствующие им коды пульта IRC приведены в разделе "Коды пульта IRC 145 F". В таблице могут быть указаны не все модели оригинальных пультов: полный список и рисунки всех заменяемых оригинальных пультов смотрите на сайте [www.pult-irc.ru](http://www.pult-irc.ru) в разделе «Инструкции к пультам».

Функции всех кнопок для некоторых кодов пульта IRC можно узнать из таблиц данного приложения и для каждого кода пульта IRC на сайте [www.pult-irc.ru](http://www.pult-irc.ru) в разделе «Инструкции к пультам».

Пульт IRC может иметь дополнительные функции (если указаны в столбце "Доп. функция"). Доступ к ним осуществляется при помощи кнопки **SHIFT** (см. в инструкции рис.1, п.16). Для доступа к дополнительным функциям нажмите кнопку **SHIFT** и, **удерживая её нажатой**, нажмите ту кнопку, дополнительная функция которой Вам необходима.

## Доступные коды пульта IRC 145 F

Номер базы кодов (диапазон кодов)	Устройство базы кодов	Доступные коды пульта
1 (101-199)	TV	101 - 102
2 (201-299)	-	Нет
3 (301-399)	AUX	301 - 311
4 (401-499)	-	Нет
5 (501-599)	TV	501 - 599
6 (601-699)	TV	601 - 699
7 (701-799)	TV	701 - 799
8 (801-899)	SAT	801 - 899
9 (901-999)	SAT	901 - 999

Базы кодов 5 – 9 являются бонусными и подходят к устройствам различных марок. Тип их устройств указан в столбце «Устройство базы кодов». Список заменяемых марок и коды к ним смотрите на сайте [www.pult-irc.ru](http://www.pult-irc.ru) в разделе «Инструкции к пультам».

## Коды пульта IRC 145 F

### Коды к TV, AUX устройствам

Модель	Устр-во	Код
AV-40	AUX, CD, DVD	311
AV-42	AUX, CD, DVD	311
DVP-315	AUX, CD, DVD	301
DVP-316	AUX, CD, DVD	304
DVP-355	AUX, CD, DVD	301
DVP-357	AUX, CD, DVD	304
DVP-360	AUX, CD, DVD	304
EG4808-2A	AUX, CD, DVD	302
HOF04C133D6	AUX, CD, DVD	308
HOF08A139GPD5	TV	102
HOF-A-ML16NA	AUX, CD, DVD	305
HOF-A-ML16NA (VER_1)	AUX, CD, DVD	308
RC-1730A	AUX, CD, DVD	307
RC-392	AUX, CD, DVD	306
RC-392-1	AUX, CD, DVD	309
RC-50	AUX, CD, DVD	310
RC-6128	TV/AUX	101
RX-828	AUX, CD, DVD	303

Функции кнопок пульта IRC 145 F

Кнопки пульта IRC 145 F	Код 101		Код 102		Код 301		Код 302		Код 303	
	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция
▲; DVD	DVD		DVD		VIRTUAL		PRE +		DVD	
AUDIO; NICAM	AUDIO		STEREO; AUDIO		AUDIO		5.1		ST/MONO	
VIDEO; SYS	TV SYSTEM		D-SUB; VGA; PC		VIDEO		OPTICAL		LD/CD	
☐; ZOOM	16:9/4:3	ZOOM	ASPECT		ZOOM				TUNER	
▼; TV	TV		TV		COLOR		PRE -		HDTV	
☐; ↻			SCART; COMPON.	SCAN; SUBTITLE	P/N		COAXIAL		MEM	SEARCH; RDS PTY
☐; LOCK	PP		SET FAV		ANGLE		RESET		SPK.CFG	
▲; FAV	ZOOM		FAV	▲; EJECT	▲; EJECT				5.1 CH	
○	○; POWER		○; POWER		○; POWER		POWER		○; STANDBY	
AV			SOURCE				CD/AUX		VCR	
⏸	MUTE		⏸; MUTE		MUTE		MUTE		⏸; MUTE	
MENU	MENU		MENU	MENU	MENU		NOISE/TEST		DSP	TEST
EXIT			EXIT		SKIP				OK/NUM	
▲	▲		▲		▲		CEN +		M.VOL +; ▲	CEN +
◀	◀		◀		◀		WOOFER -		BALL. ◀	TUNE -
OK	ENTER		ENTER		ENTER				PRESET	SPK.SELE
▶	▶		▶		▶		WOOFER +		BALL. ▶	TUNE +
▼	▼		▼		▼		CEN -		M.VOL -; ▼	CEN -
*; SETUP	LCD/TV SETUP	DVD SETUP	P.M.; PICTURE	SET UP	SET UP		MODE		LISTEN.MOD	
J; TITLE	TITLE		S.M.; SOUND	TITLE	TITLE		FM/AM		TITLE	AM/FM
☐	DVD SETUP		☐; ☐; TITLE		PROG		FRONT L -		OPTICAL	
GUIDE	EDIT		☐; CARD		BOOKMARK		FRONT L +		COAXIAL	
☐			SLEEP				FRONT R -		AUTO.IN	
☐	SUBTITLE		SUBTITLE; ASPECT	SUBTITLE	SUBTITLE		FRONT R +		ANALOG	
RED; ●	REPEAT		RED; ◀◀; FB		A-B		SURR L -		C.DELAY -	SL -
GREEN; ▶▶	A-B		GREEN; ▶▶; FF		BROWSE		SURR L +		C.DELAY +	SL +
YELLOW; ◀◀			YELLOW; ◀◀; PREV		CAPTURE		SURR R -		S.DELAY -	SR -
BLUE; ▶▶	SLOW		BLUE; ▶▶; NEXT	SLOW	SLOW		SURR R +		S.DELAY +	SR +
☐	INFO		DISPLAY		DISPLAY		RD		DISPLAY	
☐	RETURN		☐	REPEAT	REPEAT		MR		NIGHT	
VOL -	<		VOL -		VOL -		MASTER VOL -		M.VOL -; ▼	
VOL +	>		VOL +		VOL +		MASTER VOL +		M.VOL +; ▲	
CH V; ◀◀	CH V	◀◀	CH ▼		◀◀		STEP -		CHANNEL -	
CH ▲; ▶▶	CH ▲	▶▶	CH ▲		▶▶		STEP +		CHANNEL +	
+; SAT	+10; +/-		☐; +10	GOTO	+/-				BASS -	
CLEAR; X	GOTO		☐; MENU		GOTO				BASS +	
◀◀; ●	◀◀; TV SYSTEM		◀◀	☐; GOTO	◀◀		SCAN -		TREBLE -	
▶▶; ?	▶▶		▶▶; PLAY	☐; SET UP	▶▶				SW +	
■; 5	■		■; STOP	☐; SLOW	■		SCAN +		TREBLE +	
; ⏸			; PAUSE	☐; REPEAT					SW -	
			☐; ANGLE		PAUSE/STEP				#	
1, 2, ... 9, 0	1, 2, ... 9, 0		1, 2, ... 9, 0		1, 2, ... 9, 0				1, 2, ... 9, 0	

Функции кнопок пульта IRC 145 F

Кнопки пульта IRC 145 F	Код 304		Код 305		Код 306		Код 307		Код 308	
	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция	Функция	Доп. функция
▲; DVD	VIRTUAL				DVD		DVD/CARD		TUNE ▶	
AUDIO; NICAM	AUDIO				SURR		AUDIO MODE	☐; LANG.; AUDIO		
VIDEO; SYS	VIDEO						PLAY MODE	SYSTEM; CLEAR		
☐; ZOOM	ZOOM						ZOOM			
▼; TV	CAPTURE						HD/SD		TUNE ◀	
☐; ↻	P/N						AUTO SKIP		MEMORY	
☐; LOCK	ANGLE		RESET				☐; ANGLE	VIRTUAL KEY	RESET	
▲; FAV	▲; EJECT						▲			
○	○; POWER		ST-BY		POWER		○; POWER		ST-BY	
AV			INPUT SEL		AUX		DIM.; PS/M.; USB/C.		INPUT SEL	
⏸	MUTE		MUTE		MUTE		⏸; MUTE		MUTE	
MENU	MENU		MEMORY		MEMORY		MENU		MODE	
EXIT	SKIP						BOOK M.; RESUME			
▲	▲		TUNE ▶		TUNING +		▲		CENTER +	
◀	◀		PRESELECT ◀				◀		SUB-W -	
OK	ENTER				ENTER		ENTER; OK			
▶	▶		PRESELECT ▶				▶		SUB-W +	
▼	▼		TUNE ◀		TUNING -		▼		CENTER -	
*; SETUP	SET UP		MODE				SETUP			
J; TITLE	TITLE		AM/FM		AM/FM		TITLE; TOP MENU	2/5.1	AM/FM	
☐	PROG				6CH ON/OFF		REMAIN			
GUIDE	BOOKMARK						DIGEST			
☐							TIME SEARCH			
☐	SUBTITLE				SUB		SUBTITLE; ☐			
RED; ●	A-B				FRONT		REPEAT		BALANCE L	
GREEN; ▶▶	STEP				TRE		A-B		BALANCE R	
YELLOW; ◀◀	BROWSE				CEN		CAPTURE LOGO		SURR -	
BLUE; ▶▶	SLOW				BASS		▶▶; SLOW; ▶▶		SURR +	
☐	DISPLAY				DISPLAY		OSD			
☐	REPEAT						RETURN; ⏸			
VOL -	VOL -		VOLUME ▼		VOLUME -		VOLUME -; VOL -	KEY CONTROL b	VOLUME -	
VOL +	VOL +		VOLUME ▲		VOLUME +		VOLUME +; VOL +	KEY CONTROL #	VOLUME +	
CH V; ◀◀	◀◀		CHANNEL ▼		P -; CANCEL		◀◀; PREV		CHANNEL ▼	
CH ▲; ▶▶	▶▶		CHANNEL ▲		P +; ENTER		▶▶; NEXT		CHANNEL ▲	
+; SAT	+/-						10			
CLEAR; X	GOTO				CANCEL		CLEAR			
◀◀; ●	◀◀						◀◀; FR		PRESELECT ◀	
▶▶; ?	▶▶						▶▶; PLAY		PRESELECT ▶	
■; 5	■						■; STOP			
; ⏸							/STEP;   -PAUSE			
1, 2, ... 9, 0	1, 2, ... 9, 0				1, 2, ... 9, 0		1, 2, ... 9, 0			